


How To Set Up And Plant Out In A Gro-Tank System

Everything you need to know to correctly set up and 'plant out' using a Gro-Tank

SETTING UP THE GRO-TANK


(Except GT150 & 1m) 24 hrs before planting...

- Place Gro-Tank on a level surface
- Place the channel on the tank
- Add water to the top level indicator
- Wait 24 hours for the water temperature to rise
- If water is below 17°C use a submersible heater in the tank




THE PUMP

- Connect delivery tube to pump
- Connect air tube to pump
- Place pump in the tank
- Feed delivery tube through the hole in the channel
- Place air tube outside the tank
- Turn air tube anti clockwise to open fully




THE SPREADER MAT

- Cover the channel with one layer of spreader mat hanging slightly into the tank
- Plug the pump in and switch on
- Make sure the spreader mat is wet



THE TOP PLATE

- Cut holes in the top plate for the plants
- Position the top-plate in place



WHEN TO PLANT-OUT

- **DO NOT** plant out until there are plenty of white roots outside of the compost or rockwool
- If you plant too early the roots will die-back



POSITIONING PLANTS

- Place well rooted plants into position

